



RESIDENTIAL POWER VENT GAS MODELS

40 gallons

UG40-30LFPV-N1U,
UG40-32LFPV-N1U,
UG40-33LFPV-N1U,
UG40-36LFPV-N1U,
UG40-29LFPV-P1U,
UG40-32LFPV-P1U

50 gallons

UG50-34LFPV-N1U, UG50-32LFPV-P1U,
UG50-36LFPV-N1U, UG50-36LFPV-P1U,
UG50-38LFPV-N1U, UG50-59LFPV-P1U,
UG50-40LFPV-N1U, UG50-65LFPV-P1U
UG50-59LFPV-N1U,
UG50-65LFPV-N1U,

60 gallons

UG60-34MFPV-N2U,
UG60-38MFPV-N2U,
UG60-34MFPV-P2U,
UG60-38MFPV-P2U

I.D.	Part #	Description	Use With Models
1	56000152-A	Gas control valve	All
2	56001004-A	Flammable vapour sensor	All
3	14000006-A	Protective cover	All
4	58000155-A	Ignitor assembly	All
5	06000811-A	Burner assembly	UG40-30
	06000812-A	Burner assembly	UG40-32
	06000816-A	Burner assembly	UG40-33
	06000813-A	Burner assembly	UG40-36
	06001227-A	Burner assembly	UG50-34
	06001220-A	Burner assembly	UG50-36
	06001228-A	Burner assembly	UG50-38
	06001222-A	Burner assembly	UG50-40
	06001223-A	Burner assembly	UG50-59
	06001224-A	Burner assembly	UG50-65
06001512-A	Burner assembly	UG60-34	
06001513-A	Burner assembly	UG60-38	
6	KITPV001 KITPV002	Inner access door kit	UG40 UG50, UG60
7	99000155-A	Outer access door	All
8	15000028-A	Brass drain valve	All
9	19000005-A 19000006-A	Overflow tube	UG40, UG50 UG60
10	DT005330 22000403-A 22000405-A	Dip tube Dip tube Dip tube	UG40, UG50 UG50-65, UG50-59 UG60
11	MS145320 MS145410	Magnesium anode	UG40, UG50 UG60
12	18G0022 SV0Z4220	T&P relief valve	UG40, UG50 UG60
13	06000036-A 06000038-A 06000044-A	Power Twist™ flue baffle Power Twist™ flue baffle Flue Baffle	UG40, UG60 UG50 UG50-65, UG50-59
14	99000508-A	Flue reducer	UG50-65, UG50-59
15	GP2D1900	Blower motor	All*
16	GC3D4000 56001008-A 95000005-A 56001009-A	High limit switch 220°F High limit switch 180°F High limit switch 190°F High limit switch 175°F	All (prior to Sept. 2007) All (after Aug. 2007) UG50-65, UG50-59 UG50-65, UG50-59
17	GP6D4900 72000022-A 63000001-A	ABS adaptor Rubber adaptor Rubber adaptor	UG40, UG50, UG60 UG40, UG50, UG60 UG50-65, UG50-59
18	GP3D2900 60000002-A	Vacuum switch	All UG50-65, UG50-59
19	GPD04001	Blower assembly	All (prior to Sept. 2007)
	06000102-A	Blower assembly	All (after Aug. 2007)
	80000004-A	Blower assembly (Replaced by 8000008-A*)	UG50-65, UG50-59
	80000008-A	Blower assembly	UG50-65, UG50-59
20	NP022241	Outlet nipple	UG40, UG50

* Must be installed with wire connector 42000067-A on heaters built prior to Feb. 2014

For PROPANE models, substitute the following:

I.D.	Part #	Description	Use With Models
1	56000153-A	Gas control valve	All
5	06000814-A	Burner assembly	UG40-29
	06000815-A	Burner assembly	UG40-32
	06001219-A	Burner assembly	UG50-32
	06001221-A	Burner assembly	UG50-36
	06001225-A	Burner assembly	UG50-59
	06001226-A	Burner assembly	UG50-65
	06001514-A	Burner assembly	UG60-36
06001515-A	Burner assembly	UG60-40	

All propane burner manifolds are LEFT HAND THREAD



Extract from the Replacement Part Catalog (June 2015)



RESIDENTIAL POWER VENT GAS MODELS

40 gallons

UG40-32LEPV-N1U,
UG40-36LEPV-N1U,
UG40-36LEPV-N2U,
UG40-29LEPV-P1U,
UG40-32LEPV-P1U

50 gallons

UG50-34LEPV-N1U,
UG50-38LEPV-N1U,
UG50-40LEPV-N2U,
UG50-32LEPV-P1U,
UG50-36LEPV-P1U

60 gallons

UG60-36MEPV-N2U,
UG60-40MEPV-N2U,
UG60-42MEPV-N2U,
UG60-47MEPV-N2U

I.D.	Part #	Description	Use With Models
1	56000152-A	Gas control valve	UG40, UG50, UG60
2	42000023-A	Electric connector	UG40, UG50, UG60
3	56000149-A	Ignitor assembly	All
4	06000801-A	Burner assembly	UG40-32
	06000806-A	Burner assembly	UG40-36 (N1U)
	BRD04001	Burner assembly	UG40-36 (N2U)
	06001201-A	Burner assembly	UG50-34
	06001207-A	Burner assembly	UG50-38
	BRD05001	Burner assembly	UG50-40
	06001502-A	Burner assembly	UG60-36
	06001503-A	Burner assembly	UG60-40
	06001506-A	Burner assembly	UG60-42
BRD06001	Burner assembly	UG60-47	
5	ADA03001	Inner access door kit	UG40
	ADA05001		UG50, UG60
6	99000155-A	Outer access door	All
7	15000028-A	Brass drain valve	All
8	19000005-A	Overflow tube	UG40, UG50
	19000006-A		UG60
9	DT005330	Dip tube	UG40, UG50
	DT005410		UG60
10	MS145320	Magnesium anode	UG40, UG50
	MS145410		UG60
11	18G0022	T&P relief valve	All (N1U)
	SV0Z4220		All (N2U)
12	06000036-A	Power Twist™ flue baffle	UG40, UG60-40, UG40-36
	06000038-A	Power Twist™ flue baffle	UG50
	06000037-A	Power Twist™ flue baffle	UG60-47, UG60-42
13	GP2D1900	Blower motor	All
14	GC3D4000	High limit switch 220°F	All
15	GP6D4900	ABS adaptor	All
16	GP3D2900	Vacuum switch	All
17	GPD04001	Blower assembly	All
18	NP022241	Outlet nipple	All

For PROPANE models, substitute the following:

I.D.	Part #	Description	Use With Models
1	56000153-A	Gas control valve	All
3	06000800-A	Burner assembly	UG40-29
	06000802-A	Burner assembly	UG40-32
	06001200-A	Burner assembly	UG50-32
	06001204-A	Burner assembly	UG50-36

All propane burner manifolds are LEFT HAND THREAD





REPLACEMENT PARTS LIST

