


RESIDENTIAL ELECTRIC WATER HEATERS MODELS

152B (Cascade), 152E (Super Cascade 9), 172B (Cascade), 172E (Super Cascade 9)

I.D.	Part #	Description	For Use With Models	Pg
1	TH3ZX006	Upper thermostat with reset	all	6
2a	TH3ZX001	High limit reset control	all	6
2b	TH3ZX002	Upper thermostat	all	6
3	18G0002	Square flange element gasket	all	6
4	10G30/80 10G45/80	Upper square flange element Upper square flange element	all 152 all 172	4
5	18G0020 15000028-A	Plastic drain valve Brass drain valve	all B all E	12
6	TH3ZX004	Lower thermostat	all	6
7	18G0001	Thermostat bracket	all	6
8	18G0013	Machine bolt & hex head nut	all	6
9	99000060-A 99000061-A	Element access cover Element access cover	all -3F5, -3F6 all -3F7, -3F8	6
10	10G30/40 10G45/40	Lower square flange element Lower square flange element	all 152 all 172	4
11	16000011-A	Inlet nipple	all	12
12	MS145410 MS155410 MS145510 MS155520	Magnesium anode rod Magnesium anode rod Magnesium anode rod Magnesium anode rod	152B 152E 172B 172E	13
13	NP022302	Outlet nipple	all	12



REPLACEMENT PARTS LIST

